

Attach lower false ribs, fit root rib and drag strut

